

DS Vision 3000 Receiver and Receiver Long

Quick Installation Guide

This guide explains how to connect and mount the DS Vision 3000 Receiver / Receiver Long units.

1. The Receiver and Receiver Long ports

The figures below illustrates the Receiver and Receiver Long ports




Figure 1 Receiver and Receiver Long – side 1




Figure 2 Receiver – side 2




Figure 3 Receiver Long – side 2

2. Connecting the Receiver /Receiver Long

1. Connect the screen to the Video port.
2. Connect the audio/speakers to the Audio port/s. Where the audio/speakers have one stereo jack, connect it to the L&R port. Where the audio/speakers have two separate connectors connect the left speaker connector to the L port and the right speaker connector the R port.
3. Where relevant connect the Serial connection to the Serial port

2.1 Connecting to the DS Vision 3000 system

Connect the Receiver / Receiver Long units to the DS Vision 3000 system using CATx (CAT 5/5e/6/7 UTP) cables. Connect the CATx cables between the System ports of the Broadcaster/Transmitter and Receivers/Receivers Long.

2.2 Connecting to the power supply

Connect all Receiver units to the power supply with 5 VDC, 1A from the AC/DC adapters provided. **Ensure correct polarity (Center negative) and voltage.**

3. Mounting the Receiver / Receiver Long

The Receiver / Receiver Long units have VESA standard screw holes 75mm and 100mm apart, see the figure below. Use the 2 screws supplied (or the screws you may find at the back of the monitor) to connect the unit to the back of the monitor.



4. Tuning the Receiver / Receiver Long units

To tune the Receiver / Receiver Long units, see the tuning section of the User Guide. The latest User Guide can be found on our website www.minicom.com in the Support section.

www.minicom.com

International HQ

Jerusalem, Israel
Tel: + 972 2 535 9666
minicom@minicom.com

North American HQ

Linden, NJ, USA
Tel: + 1 908 486 2100
info.usa@minicom.com

European HQ

Dübendorf, Switzerland
Tel: + 41 44 823 8000
info.europe@minicom.com

Regional Offices

Germany

Kiel
Tel: + 49 431 668 7933
info.germany@minicom.com

France

Vincennes
Tel: + 33 1 49 57 00 00
info.france@minicom.com

Italy

Rome
Tel: + 39 06 8209 7902
info.italy@minicom.com

England

Camberley
Tel: + 44 (0) 1276 25053
info.uk@minicom.com

China

Shanghai
Tel: +86 (21) 64453181
michael.zhang@minicom.com

Technical support - support@minicom.com

